


REMOVAL

1. **REMOVE HYDRAULIC BRAKE BOOSTER ASSEMBLY**
(See page [BR-51](#))
2. **REMOVE BRAKE PEDAL ASSEMBLY**
 - (a) Disconnect the connector from the stop light switch.



- (b) Remove the 2 bolts.
 - (c) Remove the brake pedal assembly.
3. **DISASSEMBLY BRAKE PEDAL ASSEMBLY**
 - (a) Remove the return spring with cushion.
 - (b) Remove the stop light switch.
 - (c) Remove the pedal pad.