

CIRCUIT INSPECTION

DTC	P0500/21,23	Vehicle Speed Sensor Circuit
------------	--------------------	-------------------------------------

CIRCUIT DESCRIPTION

See page [DI-100](#).

DTC No.	Detection Item	Trouble Area
P0500/21,23	Speed signal is not input to the ECM while cruise control is set.	• Combination meter • Harness or connector between ECM and vehicle speed sensor • Vehicle speed sensor • ECM

WIRING DIAGRAM

See page [DI-100](#).

INSPECTION PROCEDURE

See page [DI-100](#).