



STARTER COMPONENTS


ST08Y-01




B04884



B04660



Magnetic Switch Assembly



◆ Non-reusable part

B04547