

PROBLEM SYMPTOMS TABLE

Flow chart No. (See page)	Component	Symptom
1. (DI-849)	Multi display	Black screen (Nothing displayed)
2. (DI-850)		No sound with Power switch pressed. ("AUTO OFF" on audio screen)
3. (DI-851)		No navigation screen displayed when "MAP", "MENU" or "DEST" switch pressed. (Screen cannot be switched.)
4. (DI-854)		No corresponding screen displayed when "AUDIO" or "Information" switch pressed.
5. (DI-855)		No navigation displayed, "Audio OFF" on audio screen and no audio sound.
6. (DI-857)		Screen cannot be dimmed in night time.
7. (DI-859)		Navigation screen not stabilized. (Synchronous error)
8. (DI-860)		Color on navigation screen is unusual (RGB signal error)
9. (DI-862)		Black screen appears when "MAP", "Menu" or "DEST" switch pressed.
10. (DI-863)		Sound of radio, cassette tape or CD only cannot be heard from speaker.
11. (DI-864)		No sound (radio, cassette tape, CD) can be heard from driver side door speaker only.
12. (DI-866)		Map DISC cannot be inserted.
13. (DI-868)		MAP screen display does not appear. (Disc Caution screen does not change.)
14. (DI-869)		MAP is displayed in white or blue screen. (Switch and vehicle position mark is displayed.)
15. (DI-870)		Touch switch does not function. (Navigation screen only)
16. (DI-871)		Touch switch does not function. (A/C control screen only)
17. (DI-872)		Panel switch does not function. (Navigation screen only)
18. (DI-873)		Panel switch does not function. (A/C control screen only)
19. (DI-874)		The screen cannot be change to night mode color.
20. (DI-876)		Vehicle position is deviated from correct point badly.
21. (DI-879)		GPS mark does not appear.

22. (DI-881)		No voice navigation.
23. (DI-882)		Vehicle position rotates without control. (Map rotates without control)
24. (DI-884)		Driving direction is opposite to moving direction of vehicle position mark.
25. (DI-885)	Radio Receiver Assembly	Radio reception poor.
26. (DI-886)		Cassette tape cannot be inserted.
27. (DI-887)		Cassette tape cannot be ejected.
28. (DI-888)		Any speaker does not work.
29. (DI-889)	DVD AUTO Changer	DVD magazine cannot be inserted.
30. (DI-891)		DVD magazine inserted, but no power.
31. (DI-893)		Power coming in, but DVD auto changer not operating..
32. (DI-895)		Sound jumps.
33. (DI-896)		Sound quality poor. (Volume faint)
34. (DI-897)		DVD magazine will not be ejected.
35. (DI-899)		Any speaker does not work.
36. (DI-900)	Power Amplifier	No power coming in.
37. (DI-903)		Any speaker does not work.
38. (DI-904)		No power coming, but woofer amplifier not operating.
39. (DI-907)	Noise	Noise occurs
40. (DI-910)		Noise produced by vibration or shock while driving.
41. (DI-911)		Noise produced when engine starts.