


# FUEL TANK AND LINE

## COMPONENTS

SF00Z-03

### CAUTION:

- Always use new gaskets when replacing the fuel tank or component parts.
- Apply the proper torque to all parts tightened



2001 LEXUS LX470 (RM802U)

B04996