


# CIGARETTE LIGHTER

FROM POWER SOURCE SYSTEM (SEE PAGE 64)



---

**SERVICE HINTS****C12 CIGARETTE LIGHTER**2-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position

1-GROUND : Always continuity

 : **PARTS LOCATION**

| Code | See Page           | Code | See Page | Code | See Page |
|------|--------------------|------|----------|------|----------|
| C12  | <a href="#">40</a> |      |          |      |          |

 : **JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

| Code | See Page           | Junction Block and Wire Harness (Connector Location) |
|------|--------------------|------------------------------------------------------|
| 2B   | <a href="#">26</a> |                                                      |
| 2D   |                    | Dash Wire and Cowl Side J/B LH (Left Kick Panel)     |

 : **GROUND POINTS**

| Code | See Page           | Ground Points Location       |
|------|--------------------|------------------------------|
| IF   | <a href="#">48</a> | Set Bolt of Cowl Side J/B LH |