


FUEL TANK AND LINE COMPONENTS

SF00Z-03

CAUTION:

- Always use new gaskets when replacing the fuel tank or component parts.
- Apply the proper torque to all parts tightened



2002 LEXUS LX470 (RM914U)

B04996