

CIRCUIT INSPECTION

DTC	1	"CODE 1. GPS antenna failure"
------------	----------	--------------------------------------

CIRCUIT DESCRIPTION

This DTC is output when the Telephone ECU (Mayday ECU) detects an open circuit of the GPS antenna.

INSPECTION PROCEDURE

Replace the GPS antenna
(See page [BO-104](#)).