

DTC	4	"CODE 4. Telephone ECU failure"
------------	----------	--

CIRCUIT DESCRIPTION

This DTC is output when there is a failure in the telephone ECU (Mayday ECU). In this case, replace the telephone ECU (Mayday ECU).

INSPECTION PROCEDURE

Replace the telephone ECU (Mayday ECU)
(See page [IN-36](#)).

HINT:

If DTC is not cleared even though the Mayday ECU is replaced, replace the Mayday Assembly (Transceiver, Back-up battery, Bus buffer ECU and Mayday ECU).