

The line condition with LEXUS Link Center is not good.

INSPECTION PROCEDURE

1 Check microphone.

CHECK:

Check that the malfunction disappears when a good microphone is installed.

RESULT:

A: Malfunction does not disappear.

B: Malfunction disappears.

NG

Replace microphone.

OK

2 Check microphone amplifier.

CHECK:

Check that the malfunction disappears when a good microphone amplifier is installed.

RESULT:

A: Malfunction does not disappear.

B: Malfunction disappears.

NG

Replace microphone amplifier.

OK

3 Check rear speaker (LH).

CHECK:

Check that the sound is heard from rear speaker (LH) when radio switch is ON.

OK:

Radio sound is heard from rear LH speaker.

NG

Go to "AUDIO SYSTEM" (See page [BE-160](#)).

OK

4**Check open and short of harness and connector between rear LH speaker and telephone ECU (Mayday ECU) (See page [IN-36](#)).****NG****Repair or replace harness or connector.****OK****5****Check transceiver.****CHECK:**

Check that the malfunction disappears when a good transceiver is installed.

RESULT:**A: Malfunction does not disappear.****B: Malfunction disappears.****NG****Replace transceiver.****OK****Check and replace telephone ECU (Mayday ECU) (See page [IN-36](#)).**