

POWER TILT AND POWER TELESCOPIC STEERING COLUMN

HOW TO PROCEED WITH TROUBLESHOOTING

DI3DT-05

Perform troubleshooting in accordance with the procedure on the following page.

