


Front Washer Switch Circuit

CIRCUIT DESCRIPTION

This circuit sends a front washer switch ON or OFF signal to ECU.

WIRING DIAGRAM



C

I26427

INSPECTION PROCEDURE

1	Check WASHER fuse.
----------	---------------------------

CHECK:

Check continuity of WASHER fuse.

OK:

Continuity

NG**Replace WASHER fuse.****OK**

2	Check wire harness between combination switch and wiper control ECU (See page IN-36).
----------	--

NG**Repair or Replace wire harness.****OK****Proceed to next circuit inspection shown on problem symptom table. (See page [DI-1185](#))**