





CYLINDER HEAD COMPONENTS


EM1VB-01




A15347







A19470




Y ^{A17674} N·m (kgf·cm, ft·lbf) : Specified torque


- ◆ Non-reusable part

* For use with SST

A19480



A05561



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A05527