

INSTALLATION

Installation is in the reverse order of removal (See page [SA-81](#)).

HINT:

After installation, fill the brake reservoir with brake fluid, bleed brake system (See page [BR-4](#)), check for leaks and ABS speed sensor signal. (See page [DI-431](#))