

DTC	C1290 / 66	Zero Point Calibration of Steering Sensor Undone
------------	-------------------	---

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1290 / 66	The steering sensor zero point calibration position vastly differs from the recorded value. (The angle becomes larger)	• Yaw rate sensor zero point calibration undone • Steering angle sensor zero point calibration undone

INSPECTION PROCEDURE

1	Perform zero point calibration. (See page DI-600)
----------	--

HINT:

This code is output when a problem occurs in a zero point calibration of the steering angle sensor and yaw rate sensor.

Therefore, clear the stored zero point calibration data and correct the zero points.

- Clear the zero point calibration data.
- Perform a zero point calibration of the steering sensor and yaw rate sensor.

NEXT

2	Is DTC output?
----------	-----------------------

- Clear the DTCs.
- Turn the ignition switch to the ON position.
- Are the same DTCs detected?

NO

Proceed to next circuit inspection shown in problem symptoms table.

YES

No problem.

HINT:

When the registered data is not equal to the input data, the DTC will be output.