

## Buck-up battery life is short.

### INSPECTION PROCEDURE

- |   |                                   |
|---|-----------------------------------|
| 1 | Check telephone ECU (Mayday ECU). |
|---|-----------------------------------|

**CHECK:**

Check that the malfunction disappears when a good telephone ECU (Mayday ECU) is installed.

**RESULT:**

**A: Malfunction does not disappear.**

**B: Malfunction disappears.**

A

Replace telephone ECU (Mayday ECU)  
(See page [IN-36](#)).

B

Check and replace back-up battery (portablephone-L battery) (See page [IN-36](#)).