

When "Service Button" is working, the connection to LEXUS Link Center cannot be made or is immediately cut off.

INSPECTION PROCEDURE

- | | |
|---|--|
| 1 | Check if trouble occurs in the service area or outside service area. |
|---|--|

CHECK:

Check if trouble occurs in the service area or outside service area.

RESULT:

A: Trouble occurs in the service area.

B: Trouble occurs in the outside service area.

B

Check and operate again in the service area.

A

- | | |
|---|--------------------|
| 2 | Check transceiver. |
|---|--------------------|

CHECK:

Check that the malfunction disappears when a good transceiver is installed.

RESULT:

A: Malfunction does not disappear.

B: Malfunction disappears.

B

Replace transceiver.

A

3 Check telephone antenna.

Check that malfunction disappears when a new antenna and telephone antenna cable are installed.

RESULT:

A: Malfunction does not disappear.

B: Malfunction disappears.

B

Repair or replace telephone antenna cable or antenna

A**4 Check for open and short circuit in harness and connector between transceiver and telephone ECU (Mayday ECU) (See page [IN-36](#)).****NG**

Repair or replace harness or connector.

OK

Check and replace telephone ECU (Mayday ECU) (See page [IN-36](#)).