

After the connection to LEXUS Link Center, no voice comes out.

INSPECTION PROCEDURE

- | | |
|---|--------------------------|
| 1 | Check telephone antenna. |
|---|--------------------------|

CHECK:

Check that the malfunction disappears when a good telephone antenna and cable are installed.

Result:

A: Malfunction does not disappear.

B: Malfunction disappears.

B

Replace or replace telephone antenna cable or antenna.

A

- | | |
|---|---|
| 2 | Check open and short of harness between transceiver and telephone ECU (Mayday ECU) (See page IN-36). |
|---|---|

NG

Repair or replace harness or connector.

OK

Check and replace telephone ECU (Mayday ECU) (See page [IN-36](#)).