

**29. Power comes in, but DVD auto changer does not operate.****INSPECTION PROCEDURE**

**1** Is DVD inserted with correct side up?

**NO**

Insert correctly.

**YES**

**2** Function OK if different DVD magazine is inserted?

**YES**

Replace DVD magazine.

**NO**

**3** Check wire harness and connector between RSA panel and DVD auto changer (See page [IN-36](#)).

**NG**

Repair or replace wire harness or connector.

**OK**

**4** Is temperature inside cabin hot?

**YES**

Protective circuit in operation.

**NO**

|   |                                   |
|---|-----------------------------------|
| 5 | Does temperature suddenly change? |
|---|-----------------------------------|

**YES****Formation of condensation due to temp. changes.****NO****Check and replace DVD auto changer.**