

6. Screen cannot be dimmed in night time.

INSPECTION PROCEDURE

- | | |
|---|---|
| 1 | Check if the screen is dimmed at night. (With the light control switch ON, do all screens except the navigation screen appear in Night Mode?) |
|---|---|

NG

Check the light control switch.

OK

- | | |
|---|---|
| 2 | Check "Display check mode" (Vehicle Signal Check) |
|---|---|

CHECK:

Check the input signal TAIL and ADIM/TCAN.

OK:

Status is normal

NG

Check and replace multi display.

OK

- | | |
|---|--------------------------|
| 3 | Check the multi display. |
|---|--------------------------|

CHECK:

Check voltage terminal DR.

OK:

DR: See "Multi display" of "TERMINAL OF ECU".

NG

Replace or repair wire harness or connector.

OK

Check and replace the multi display.