
















TRANSFER






SST (Special Service Tools)

PP1YY-02

	09316-12010 Transfer Bearing Replacer	Center differential
	09316-20011 Transfer Bearing Replacer	Front extension housing, Rear extension housing
	09316-60011 Transmission & Transfer Bearing Replacer	
	(09316-00011) Replacer Pipe	Front extension housing, Rear extension housing, Idler gear, Transfer assembly, Center differential, Input shaft
	(09316-00021) Replacer "A"	Rear extension housing
	(09316-00031) Replacer "B"	Front extension housing, Rear extension housing, Idler gear, Transfer assembly, Input shaft
	(09316-00041) Replacer "C"	Front extension housing, Rear extension housing
	(09316-00061) Replacer "E"	Front extension housing
	(09316-00071) Replacer "F"	Idler gear, Front extension housing
	09325-12010 Transmission Oil Plug	Rear extension housing
	09950-00020 Bearing Remover	Idler gear, Center differential
	09950-00030 Bearing Remover Attachment	Center differential

PREPARATION - TRANSFER

	09950-40011 Puller B Set	
	(09951-04010) Hanger 150	Idler gear
	(09951-04020) Hanger 200	Input shaft, Front extension housing, Transfer assembly
	(09952-04010) Slide Arm	Input shaft, Idler gear, Front extension housing, Transfer assembly
	(09953-04030) Center Bolt 200	Input shaft, Idler gear, Front extension housing, Transfer assembly
	(09954-04010) Arm 25	Input shaft, Front extension housing, Transfer assembly, Idler gear
	(09954-04020) Arm 100	Front extension housing
	(09955-04011) Claw No.1	Input shaft
	(09955-04021) Claw No.2	Front extension housing
	(09955-04051) Claw No.5	Front extension housing
	(09955-04061) Claw No.6	Idler gear, Transfer assembly
	(09957-04010) Attachment	Input shaft, Idler gear, Front extension housing, Transfer assembly
	(09958-04011) Holder	Input shaft, Idler gear, Front extension housing

	09950-60010 Replacer Set	
	(09951-00270) Replacer 27	Transfer assembly
	(09951-00320) Replacer 32	Transfer assembly, Center differential
	(09951-00330) Replacer 33	Idler gear
	(09951-00400) Replacer 40	Input shaft
	09950-60020 Replacer Set No.2	
	(09951-00790) Replacer 79	Transfer assembly
	(09951-00890) Replacer 89	Transfer assembly
	09950-70010 Handle Set	Transfer assembly, Center differential
	(09951-07150) Handle 150	Transfer assembly