

# AUTOMATIC TRANSMISSION

DICEB-03

## PRECAUTION

**NOTICE:**

Perform the RESET MEMORY (AT initialization) when replacing the automatic transmission assy, engine assy or the ECM (See page [DI-368](#)).

**HINT:**

Initialization can not be completed by only disconnecting the battery terminal.