

27. DVD MAGAZINE CANNOT BE INSERTED

INSPECTION PROCEDURE

1 Is DVD magazine already inserted?

YES

Eject DVD magazine.

NO

2 Check the DVD auto changer.

PREPARATION:

Disconnect the DVD auto changer connector.

CHECK:

Check voltage terminal +B.

OK:

+B: 10 – 14 V

CHECK:

Check voltage terminal ACC when turning the ignition switch to ACC or ON position.

OK:

ACC: 10 – 14 V

CHECK:

Check continuity terminal GND.

OK:

GND: Continuity

NG

Replace or repair wire harness or connector.

OK

Check and replace DVD auto changer.