


Stop Light Switch Circuit

CIRCUIT DESCRIPTION

This circuit sends a stop light switch ON or OFF signal to ECU.

WIRING DIAGRAM



C

I25579

INSPECTION PROCEDURE

1 Check stop light switch (See page [BE-63](#)).

NG

Replace stop light switch.

OK

2 Check wire harness between stop light switch and wiper control ECU
(See page [IN-36](#)).

NG

Repair or replace wire harness.

OK

Proceed next circuit inspection shown on
problem symptom table. (See page [DI-1358](#))