




INSPECTION

INSPECT FUEL TANK AND LINE

- Check the fuel lines from cracks or leakage, and all connections for deformation.
- Check the fuel tank vapor vent system hoses and all connections for looseness, sharp bends or damage.
- Check the fuel tank for deformation, cracks, fuel leakage or tank band looseness.
- Check the filler neck for damage or fuel leakage.
- Hose and pipe connections are as shown in the illustration.

If a problem is found, repair or replace the parts as necessary.

