






















Position of Parts in Instrument Panel



- A 13 Accel Position Sensor
 - A 18 A/C Solar Sensor
 - A 19 A/C Thermistor
 - A 24 AHC Main Relay
 - A 25 Air Inlet Control Servo Motor
 - A 26 Air Mix Control Servo Motor
 - A 27 Air Vent Mode Control Servo Motor
 - A 28 Airbag Squib (Front Passenger Airbag Assembly)
 - A 29 Airbag Squib (Steering Wheel Pad)
 - A 30 Ashtray Illumination
 - A 31 Auto Antenna Control Relay
 - A 32 Automatic Light Control Sensor
 - A 39 ABS & BA & TRAC & VSC ECU
 - A 40 ABS & BA & TRAC & VSC ECU
 - A 41 ABS & BA & TRAC & VSC ECU
 - A 42 ABS & BA & TRAC & VSC ECU
 - A 47 A/C Control Assembly
 - A 48 A/C Control Assembly
 - A 49 A/C Control Assembly
 - A 50 Auto Wiper ECU
 - A 51 Auto Wiper ECU
 - A 52 A/T Shift Lever Illumination , Shift Lock Control ECU
-
- B 1 Blower Motor Controller
 - B 7 Body ECU
 - B 8 Body ECU
 - B 9 Body ECU

Position of Parts in Instrument Panel



Position of Parts in Instrument Panel

