


Position of Parts in Instrument Panel



- C 7 Center Diff. Lock Control Relay
- C 12 Cigarette Lighter
- C 13 Cigarette Lighter Illumination
- C 14 Combination Meter
- C 15 Combination Meter
- C 16 Combination Meter
- C 17 Combination Meter
- C 18 Combination SW
- C 20 Combination SW
- C 21 Combination SW
- C 31 Center Airbag Sensor Assembly
- C 32 Center Airbag Sensor Assembly
- C 33 Center Airbag Sensor Assembly
- C 34 Center Cluster Integration Panel
- C 35 Combination SW
- C 36 Combination SW , Steering Sensor




















- D 7 Damping Mode Select SW and Height Control SW
- D 8 Data Link Connector 3
- D 32 DVD Automatic Changer

- E 5 Electronically Controlled Transmission Pattern Select SW
- E 6 Engine Control Module
- E 7 Engine Control Module
- E 8 Engine Control Module
- E 9 Engine Control Module
- E 10 Engine Control Module

- G 3 Glove Box Light
- G 5 Gateway ECU

- I 18 Ignition SW


Position of Parts in Instrument Panel



Position of Parts in Instrument Panel


E 6

White




E 7

White




E 8

White




E 9

White




E 10

White




G 3

White



G 5

White



I 18

White

