




- B 1 Fog Light Assembly LH
- B 2 Fog Light Assembly RH
- B 3 No.1 Ultrasonic Sensor RH
- B 4 No.1 Ultrasonic Sensor LH

- U 1 Knock Control Sensor (Bank 1 Sensor 1)
- U 2 Knock Control Sensor (Bank 2 Sensor 1)
- U 3 Knock Control Sensor (Bank 1 Sensor 2)
- U 4 Knock Control Sensor (Bank 2 Sensor 2)

- z 17 Front Speed Sensor RH
- z 18 Front Speed Sensor LH
- z 43 Front Height Control Sensor Sub-Assembly RH
- z 44 Front Height Control Sensor Sub-Assembly LH

Position of Parts in Engine Compartment

