






Position of Parts in Instrument Panel (RHD)




I80	No. 14 Junction Connector
I81	No. 15 Junction Connector
I82	No. 16 Junction Connector
I83	No. 17 Junction Connector
I84	No. 18 Junction Connector
I85	No. 19 Junction Connector
I86	No. 20 Junction Connector
I87	No. 21 Junction Connector
I88	No. 22 Junction Connector
I89	No. 23 Junction Connector
I90	No. 24 Junction Connector
I91	No. 25 Junction Connector
I92	No. 26 Junction Connector
I93	No. 1 CAN Junction Connector
I94	No. 2 CAN Junction Connector
I95	No. 3 CAN Junction Connector
I96	No. 4 CAN Junction Connector
I97	No. 5 CAN Junction Connector
I99	Radio Receiver Assembly
I101	Multi-Display Assembly
I102	Radio Receiver Assembly
I103	No. 1 Stereo Jack Adapter Assembly
I104	Radio Receiver Assembly
I105	Combination Meter Assembly
I143	No. 1 Stereo Jack Adapter Assembly
I165	No. 8 CAN Junction Connector
I167	No. 10 CAN Junction Connector
I171	Multi-Display Assembly
I172	No. 1 Stereo Jack Adapter Assembly

Position of Parts in Instrument Panel (RHD)




Position of Parts in Instrument Panel (RHD)

I83
Black




90980-12372
(LHD)

I83
White




90980-12372
(RHD)

I84
Black







90980-12372
(LHD)

I84
Gray




90980-12372
(RHD)

Position of Parts in Instrument Panel (RHD)




Position of Parts in Instrument Panel (RHD)

I88
Black




90980-12372

I89
White




90980-12372

I90
Black



90980-12372



I91
Gray



90980-12372
(LHD)



Position of Parts in Instrument Panel (RHD)

I91
Black





90980-12372
(RHD)

I92
White





90980-12737

I93
White





90980-12A58

I94
White













90980-12A58

I95
White



90980-12A58



Position of Parts in Instrument Panel (RHD)



Position of Parts in Instrument Panel (RHD)

I165



White



90980-12C68

I167

White



90980-12372

I171

Blue



90980-12C80

I172

Brown



90980-12C98