






Position of Parts in Instrument Panel (LHD)




I85	No. 19 Junction Connector
I86	No. 20 Junction Connector
I91	No. 25 Junction Connector
I92	No. 26 Junction Connector
I93	No. 2 CAN Junction Connector
I94	No. 3 CAN Junction Connector
I95	No. 4 CAN Junction Connector
I96	No. 5 CAN Junction Connector
I97	No. 6 CAN Junction Connector
I98	Radio Receiver Assembly
I99	Radio Receiver Assembly
I100	Telematics Transceiver
I101	Multi-Display Assembly
I102	Radio Receiver Assembly
I103	No. 1 Stereo Jack Adapter Assembly
I104	Radio Receiver Assembly
I105	Combination Meter Assembly
I108	Multi-Display Assembly
I109	Radio Receiver Assembly
I114	Vehicle Sound Switch
I115	Hybrid Vehicle Control ECU
I116	Hybrid Vehicle Control ECU
I117	Stereo Component Equalizer Assembly
I118	No. 1 Speaker with Box Assembly
I171	Multi-Display Assembly
I172	No. 1 Stereo Jack Adapter Assembly
I173	Multi-Display Assembly

Position of Parts in Instrument Panel (LHD)




Position of Parts in Instrument Panel (LHD)

I86
Black




90980-12372
(RHD From Sep. 2017 Production)

I91
Gray




90980-12372
(LHD)

I91
Black




90980-12372
(RHD)

I92
White



90980-12737



I93
White



90980-12A58



Position of Parts in Instrument Panel (LHD)

I94
White





90980-12A58

I95
White





90980-12A58

I96
White



90980-12372

I97
White



90980-12372
(LHD Before May 2018 Production)

Position of Parts in Instrument Panel (LHD)

