




Position of Parts in Instrument Panel (RHD)



I93	No. 2 CAN Junction Connector
I94	No. 3 CAN Junction Connector
I95	No. 4 CAN Junction Connector
I96	No. 5 CAN Junction Connector
I97	No. 6 CAN Junction Connector
I99	Radio Receiver Assembly
I101	Multi-Display Assembly
I102	Radio Receiver Assembly
I103	No. 1 Stereo Jack Adapter Assembly
I104	Radio Receiver Assembly
I105	Combination Meter Assembly
I108	Multi-Display Assembly
I109	Radio Receiver Assembly
I114	Vehicle Sound Switch
I115	Hybrid Vehicle Control ECU
I116	Hybrid Vehicle Control ECU
I117	Stereo Component Equalizer Assembly
I118	No. 1 Speaker with Box Assembly
I119	Radio Receiver Assembly
I120	Radio Receiver Assembly
I121	Radio Receiver Assembly
I122	Radio Receiver Assembly
I123	Radio Receiver Assembly
I124	Windshield Wiper Switch Assembly
I125	Windshield Wiper Switch Assembly
I126	Headlight Dimmer Switch Assembly
I127	Theft Warning Tilt Sensor
I128	Airbag Cut Off Switch Cylinder Sub-Assembly
I129	Double Lock Door Control Relay Assembly
I139	Radio Receiver Assembly
I142	Radio Receiver Assembly
I143	No. 1 Stereo Jack Adapter Assembly
I147	Navigation Antenna Assembly
I149	Radio Receiver Assembly
I150	Navigation Antenna Assembly
I167	No. 11 CAN Junction Connector
I171	Multi-Display Assembly
I172	No. 1 Stereo Jack Adapter Assembly
I173	Multi-Display Assembly



Position of Parts in Instrument Panel (RHD)

I93
White





90980-12A58

I94
White





90980-12A58

I95
White




90980-12A58

I96
White




90980-12372


Position of Parts in Instrument Panel (RHD)




90980-12372
(LHD Before May 2018 Production)




90980-12372
(RHD Before May 2018 Production, From May 2018 Production)




90980-12A52




90980-12593




90980-12972




90980-12A52




90980-12A73




90980-12593




90980-12596




90980-50059




90980-12113




90980-12429




90980-12431




90980-12553



90980-10935




90980-10996




90980-10997


Position of Parts in Instrument Panel (RHD)




90980-12555




90980-12905




90980-12460




90980-12358




90980-12359




90980-12460




90980-12303




90980-12063




90980-10807




90980-12957




90980-12A52




90980-12A69




90980-50024




90980-50059




90980-50024




90980-12C68



90980-12C80



90980-12C98



90980-12C82