



Position of Parts in Seat (RHD Rear Seat)




P8	Rear Power Seat Switch RH
Q20	Rear Power Seat Switch LH
Q49	Rear Seat Inner Belt with Center Assembly RH
Q50	Rear Seat Inner Belt Assembly LH
h1	Rear Power Seat Reclining Position Motor RH (Rear Seat Back Frame Sub-Assembly RH)
h2	Rear Power Seat Reclining Position Motor RH (Rear Seat Back Frame Sub-Assembly RH)
h3	Fold Seat Control ECU RH
h4	Fold Seat Control ECU RH
h5	Rear Seat Inner Belt with Center Assembly RH
h6	Bench Type Rear Seat Cushion Cover
h7	Separate Type Rear Seat Back Cover RH
i1	Rear Power Seat Reclining Position Motor LH (Rear Seat Back Frame Sub-Assembly LH)
i2	Rear Power Seat Reclining Position Motor LH (Rear Seat Back Frame Sub-Assembly LH)
i3	Fold Seat Control ECU LH
i4	Fold Seat Control ECU LH
i5	Rear Seat Inner Belt Assembly LH
i6	Bench Type Rear Seat Cushion Cover
i7	Separate Type Rear Seat Back Cover LH


Position of Parts in Seat (RHD Rear Seat)




90980-12558




90980-12558




90980-12413




90980-12413




90980-12341




90980-12344




90980-12557




90980-12540




90980-12366




90980-12734




90980-12734




90980-12344




90980-12341




90980-12557




90980-12540



90980-12341



90980-12734



90980-12734