




A40	Pedestrian Protection Sensor LH
A41	Pop Up Hood Lifter Assembly LH
A42	Windshield Washer Motor and Pump Assembly
A43	Level Warning Switch Assembly
A44	Headlight Cleaner Control Relay
A45	Headlight Cleaner Motor and Pump Assembly
A64	No. 1 Wiring Harness Condenser Assembly
A65	No. 1 Junction Connector
A66	No. 2 Junction Connector
A68	No. 1 Ground Junction Connector
A69	No. 4 Junction Connector
A70	ECM
A71	ECM
A73	Battery
A77	Front Wiper Deicer (Windshield Glass)

Position of Parts in Engine Compartment (LHD 2GR-FSE)

