



# Position of Parts in Instrument Panel (LHD)

- \* 2:w/ Power Tilt and Power Telescopic
- \* 3:w/o Power Tilt and Power Telescopic
- \* 6:Before Oct. 2015 Production
- \* 7:From Oct. 2015 Production
- \* 8:Before Nov. 2017 Production
- \* 9:From Nov. 2017 Production
- \* 20:Before Oct. 2018 Production
- \* 21:From Oct. 2018 Production




|      |                                                                 |
|------|-----------------------------------------------------------------|
| O30  | Spiral Cable with Sensor Sub-Assembly                           |
| O35  | Stereo Component Equalizer Assembly                             |
| O36  | Vehicle Sound Switch                                            |
| O37  | No. 1 Speaker with Box Assembly                                 |
| O38  | Absorber Control ECU                                            |
| O40  | Skid Control Buzzer Assembly                                    |
| O41  | Double Lock Door Control Relay Assembly                         |
| O42  | Tire Pressure Monitor Initiator Driver                          |
| O43  | Clearance Warning ECU Assembly                                  |
| O44  | No. 1 Clearance Warning Buzzer                                  |
| O45  | Shift Lock Control ECU (Transmission Floor Shift Assembly)      |
| O46  | Network Gateway ECU                                             |
| O47  | Lower No. 1 Instrument Panel Airbag Assembly                    |
| O49  | Engine Switch                                                   |
| O50  | Airbag ECU Assembly                                             |
| O52  | Lower No. 2 Instrument Panel Airbag Assembly                    |
| O53  | Glove Box Light Assembly                                        |
| O54  | Front No. 2 Speaker Assembly RH                                 |
| O55  | Front No. 2 Speaker Assembly LH                                 |
| O56  | Front No. 3 Speaker Assembly                                    |
| O57  | Radio Receiver Assembly                                         |
| O58  | Radio Receiver Assembly                                         |
| O59  | Radio Receiver Assembly                                         |
| O60  | Multi-Display Assembly                                          |
| O61  | Clock Assembly                                                  |
| O64  | A/C Control Assembly                                            |
| O66  | No. 1 Stereo Jack Adapter Assembly                              |
| O67  | Radio Setting Condenser                                         |
| O68  | Radio Receiver Assembly                                         |
| O69  | Radio Receiver Assembly                                         |
| O70  | Radio Receiver Assembly                                         |
| O71  | Radio Receiver Assembly                                         |
| O72  | Radio Receiver Assembly                                         |
| O73  | Radio Receiver Assembly                                         |
| O75  | Remote Operation Controller Assembly                            |
| O76  | Remote Operation Controller Assembly                            |
| O77  | Transmission Control Switch (Transmission Floor Shift Assembly) |
| O78  | Combination Switch Assembly                                     |
| O79  | No. 1 Power Outlet Socket Assembly                              |
| O141 | Double Lock Door Control Relay Assembly                         |
| O157 | Network Gateway ECU                                             |
| O164 | No. 1 Stereo Jack Adapter Assembly                              |
| O165 | Remote Operation Controller Assembly                            |
| O201 | Clock Assembly                                                  |


## Position of Parts in Instrument Panel (LHD)




90980-12160




90980-12553




90980-12113




90980-10935




82824-50310




90980-10860




90980-10807




90980-12558




90980-12924




90980-10825




90980-12366




90980-12423




90980-12452




90980-12368




90980-12391




90980-12452




90980-11918



90980-12808






















90980-12808




90980-12808

# Position of Parts in Instrument Panel (LHD)




## Position of Parts in Instrument Panel (LHD)

O141  
White




90980-12812

O157  
Black




90980-12912

O164  
White




90980-12910

O165  
Black



90980-12361

O201  
Black



90980-12558