


Position of Parts in Instrument Panel (RHD)


* 16:w/ LEXUS Navigation System
* 17:w/o LEXUS Navigation System



O141 Double Lock Door Control Relay Assembly
O142 Engine Stop & Start Solenoid Filter
O143 Engine Stop and Start ECU
O158 Radio Receiver Assembly
O159 Radio Receiver Assembly
O160 Radio Receiver Assembly
O161 Radio Receiver Assembly
O162 Navigation ECU
O180 No. 14 CAN Junction Connector
O181 No. 14 CAN Junction Connector
O182 No. 14 CAN Junction Connector
O183 No. 14 CAN Junction Connector
O184 No. 14 CAN Junction Connector
O185 Radio Receiver Assembly
O186 Radio Receiver Assembly
O188 Radio Receiver Assembly
O197 No. 19 CAN Junction Connector


Position of Parts in Instrument Panel (RHD)

O141
White




90980-12812

O142
White




90980-12558

O143
Black




82824-12510

O158
White




82824-52380

O159
White




90980-12761

O160
White




90980-12760

O161
Black




90980-12C39

O162
Black




90980-12912

O180
White




90980-12827

O181
White




90980-12827

O182
White



90980-12827

O183
White



90980-12827

Position of Parts in Instrument Panel (RHD)

