



Position of Parts in Engine Compartment (LHD)

* 3: Before Aug. 2016 Production
* 4: From Aug. 2016 Production




A40	Pedestrian Protection Sensor LH
A41	Pop Up Hood Lifter Assembly LH
A42	Windshield Washer Motor and Pump Assembly
A43	Level Warning Switch Assembly
A44	Headlight Cleaner Control Relay
A45	Headlight Cleaner Motor and Pump Assembly
A64	No. 1 Wiring Harness Condenser Assembly
A65	No. 1 Junction Connector
A66	No. 2 Junction Connector
A68	No. 1 Ground Junction Connector
A69	No. 4 Junction Connector
A72	ECM
A77	Front Wiper Deicer (Windshield Glass)
A79	Skid Control ECU Assembly
A82	Inverter with Converter Assembly
A83	Inverter with Converter Assembly
A84	Inverter with Converter Assembly
A85	Terminal Block Assembly


Position of Parts in Engine Compartment (LHD)




90980-12490




90980-12698




90980-11019




90980-11068




90980-11194




90980-10981




90980-11156




90980-12372




90980-12372



90980-11194




90980-11661




90980-12931



Position of Parts in Engine Compartment (LHD)




90980-11407



90980-11904



90980-12995



90980-12520

