


Position of Parts in Instrument Panel <LHD>



G 36 Navigation Receiver Assembly
G 37 Radio Receiver Assembly
G 38 Radio Receiver Assembly
G 39 Navigation Receiver Assembly
G 40 Radio Receiver Assembly
G 41 Multi-Display Assembly
G 43 Remote Operation Switch
G 44 Remote Operation Switch
G 45 Junction Connector
G 46 Multi-Display Controller Sub-Assembly
G 47 Navigation Receiver Assembly
G 48 Multi-Display Assembly
G 49 Navigation Receiver Assembly
G 50 Multi-Display Assembly
G 51 Navigation Receiver Assembly
G 52 Navigation Receiver Assembly
G 53 Telematics Transceiver
G 54 Radio Receiver Assembly
G 55 Multi-Display Assembly
G 56 Telephone Transceiver Assembly
G 57 Radio Receiver Assembly
G 58 Radio Receiver Assembly
G 59 Radio Receiver Assembly
























H 1 Meter Mirror Sub-Assembly
H 2 Front No. 4 Speaker Assembly
H 3 Automatic Light Control Sensor

O 1 Certification ECU Assembly
O 2 4WD ECU Assembly
O 8 Airbag Sensor Assembly
O 9 Front Indoor Electrical Key Oscillator
O 44 Multi-Display Controller Sub-Assembly


P 9 Multi-Display Controller Sub-Assembly
P 10 Airbag Sensor Assembly
P 46 Multi-Display Controller Sub-Assembly
P 47 Multi-Display Controller Sub-Assembly

S 1 Oxygen Sensor (Bank 1 Sensor 2)


Position of Parts in Instrument Panel <LHD>




White




White




Blue




White




White




Yellow




White




Brown




White




Yellow



White



White



Gray

