



























































- *15 : w/o Power Back Door
- *23 : Before Mar. 2012 Production
- *24 : From Mar. 2012 Production
- *27 : HDD Navigation System Type
- *28 : LEXUS Display Audio System Type
- *29 : 9-Speaker Sound System Type
- *30 : Before Aug. 2013 Production
- *31 : From Aug. 2013 Production












*17 : w/o Theft Warning Siren Assembly
*18 : w/ Theft Warning Siren Assembly
*21 : Before Aug. 2010 Production
*22 : From Aug. 2010 Production





















F 14
White




F 15
Black




F 16
Black




F 17
White




F 22
Black



F 31
White




F 37
Black




F 44
Black




F 45
White




F 58
White




F 63
Black



F 64
Black



F 65
White



F 66
White

