




Audio System (w/o LEXUS Navigation System), Back Guide Monitor System (w/o LEXUS Navigation System)




Audio System (w/o LEXUS Navigation System), Back Guide Monitor System (w/o LEXUS Navigation System)



Audio System (w/o LEXUS Navigation System), Back Guide Monitor System (w/o LEXUS Navigation System)



Audio System (w/o LEXUS Navigation System), Back Guide Monitor System (w/o LEXUS Navigation System)



17

18

19


20

- * 1 : 9 Speaker
- * 2 : 12 Speaker
- * 3 : w/ Telematics Transceiver
- * 4 : w/o Telematics Transceiver

The diagram illustrates the electrical connections for the front and rear speaker assemblies. It features several key components and wiring paths:

- Frontal Terminals:** FR+, FR-, CTR+, CTR-, WF1+, WF1-, FL+, and FL-.
- Relays:** KJ1 (Front No. 2 Speaker Assembly RH), KJ1 (Front No. 3 Speaker Assembly), JS4 (Rear No. 3 Speaker Assembly), and KJ1 (Front No. 2 Speaker Assembly LH).
- Speakers:** K6 (Front No. 2 Speaker Assembly RH), K5 (Front No. 2 Speaker Assembly RH), K2 (Front No. 3 Speaker Assembly), K7 (Front No. 2 Speaker Assembly LH), and K8 (Front No. 2 Speaker Assembly LH).
- Telematics Transceivers:** Two transceivers are shown, each with a 59-pin connector.
- Wiring Labels:** LG, L, B, Y, P, V, GR, W, BR, R, and their respective counts in parentheses.
- Terminal Numbers:** 1, 2, 3, 4 on the components.

Audio System (w/o LEXUS Navigation System), Back Guide Monitor System (w/o LEXUS Navigation System)



Audio System (w/o LEXUS Navigation System), Back Guide Monitor System (w/o LEXUS Navigation System)

