



[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]



(Cont. Next Page)

[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]

(Cont'd)



(Cont. Next Page)


[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]

* 1:2GR-FKS
 * 2:8AR-FTS
 * 3:5A ECU-IG2 NO.1 (*1)
 7.5A BBC NO.5 (*2)

* 4:30A ST (*1)
 30A ST NO.1 (*2)
 * 5:80A FAN (*1)
 40A FAN NO.1 (*2)

* 7:40A FAN NO.2 (*2)
 40A A/C RR (*1 *8)
 * 8:w/ Rear No. 2 Seat

(Cont'd)




(Cont. Next Page)

[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]

(Cont'd)

* 1:2GR-FKS
* 2:8AR-FTS




(Cont. Next Page)

[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]

* 1:2GR-FKS * 6:WSH NZL HTR Relay (*1)
* 2:8AR-FTS ST NO.2 Relay (*2)

(Cont'd)



(Cont. Next Page)

[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]

