


① : Engine Room R/B No. 1	Left Engine Compartment
○ : Engine Room J/B No. 1	



① : Engine Room R/B No. 1


○ : Engine Room J/B No. 1

Left Engine Compartment

Unit A

- | | | |
|------------------------|-----------------------|---------------------------|
| * 1:2GR-FKS | * 12:50A PTC HTR NO.1 | * 24:50A HWD NO.2 |
| * 2:8AR-FTS | * 13:50A HTR | * 26:30A BBC NO.3 |
| * 3:100A J/B-AM | * 14:150A ALT | * 27:5A ECU-IG2 NO.1 (*1) |
| * 4:30A H-LP CLN | * 15:30A ST (*1) | 7.5A BBC NO.5 (*2) |
| * 5:30A PTC HTR NO.3 | 30A ST NO.1 (*2) | * 28:w/ Rear No. 2 Seat |
| * 6:30A PTC HTR NO.2 | * 16:30A ABS NO.2 | * 29:7.5A P/OUTLET NO.2 |
| * 7:30A P/SEAT R/R | * 17:40A J/B-BAT | |
| * 8:30A P/SEAT R/L | * 18:50A BBC NO.1 | |
| * 9:30A PBD | * 19:50A BBC NO.2 | |
| * 10:40A FAN NO.2 (*2) | * 20:50A ABS NO.1 | |
| 40A A/C RR (*1 *28) | * 21:80A EPS | |
| * 11:80A FAN (*1) | * 22:30A WIPER | |
| 40A FAN NO.1 (*2) | * 23:50A HWD NO.1 | |


Top View



① : Engine Room R/B No. 1	Left Engine Compartment
○ : Engine Room J/B No. 1	

Unit A

Back View



① : Engine Room R/B No. 1	Left Engine Compartment
○ : Engine Room J/B No. 1	

Unit B

Back View

Top View

