


Position of Parts in Instrument Panel (RHD)




J82	Front Refreshing Seat Switch
J83	Integration Control & Panel Assembly
J84	Integration Control & Panel Assembly
J85	Electric Parking Brake Switch Assembly
J86	No. 1 Power Outlet Socket Assembly
J91	Radio Receiver Assembly
J92	No. 3 Power Outlet Socket Assembly
J93	No. 2 CAN Junction Connector
J94	No. 5 Junction Connector
J95	No. 3 CAN Junction Connector
J96	No. 4 CAN Junction Connector
J97	No. 5 CAN Junction Connector
J98	No. 6 CAN Junction Connector
J99	No. 7 CAN Junction Connector
J100	No. 6 Junction Connector
J101	No. 7 Junction Connector
J102	No. 8 Junction Connector
J103	No. 8 Junction Connector
J104	No. 9 Junction Connector
J105	No. 9 Junction Connector
J106	No. 10 Junction Connector
J107	No. 10 Junction Connector
J108	No. 11 Junction Connector
J109	No. 11 Junction Connector
J110	No. 12 Junction Connector
J111	No. 13 Junction Connector
J112	No. 13 Junction Connector
J113	No. 14 Junction Connector
J114	No. 15 Junction Connector
J115	No. 16 Junction Connector
J117	No. 18 Junction Connector
J118	No. 19 Junction Connector
J119	No. 20 Junction Connector
J120	No. 21 Junction Connector
J121	No. 1 Ignition Relay
J122	Radio Receiver Assembly
J123	Stereo Component Amplifier Assembly
J126	Radio Receiver Assembly
J127	Combination Meter Assembly
J128	Multi-Display Assembly
J129	Radio Receiver Assembly
J130	Radio Receiver Assembly
J132	Radio Receiver Assembly
J133	No. 1 Stereo Jack Adapter Assembly
J134	Multi-Display Assembly
J135	Parking Assist ECU
J138	Accessory Meter Assembly
J139	Accessory Meter Assembly
J140	Radio Receiver Assembly
J141	No. 37 Junction Connector
J142	No. 37 Junction Connector

Position of Parts in Instrument Panel (RHD)

J82


White



90980-12550

J83


White



90980-12412

J84


Blue



90980-12372

J85


Black



82824-33470

J86


White



90980-12498

J91


Black



90980-12733

J92


Blue



90980-12498

J93


White



90980-12A58

J94


Gray



90980-11542

J95


White



90980-12A58


Position of Parts in Instrument Panel (RHD)

J96
Blue




90980-12372

J97
Gray




90980-12372

J98
Black



90980-12372


J99
Black



90980-12372


Position of Parts in Instrument Panel (RHD)

J100
White




90980-12372

J101
Black




90980-12372

J102
Black



90980-12372


J103
White



90980-12372


Position of Parts in Instrument Panel (RHD)

J104
White




90980-12372

J105
Gray




90980-12372

J106
Black



90980-12372

J107
Gray




90980-12372

Position of Parts in Instrument Panel (RHD)

J108


Blue



90980-12372

J109


Gray



90980-12372

J110


Gray



90980-12372
(Before Aug. 2016 Production)

J110


White



90980-12372
(From Aug. 2016 Production)

J111


Black



90980-12737


Position of Parts in Instrument Panel (RHD)

J112
White




90980-12737

J113
Gray




90980-12372

J114
Blue




90980-12372

J115
Blue





















90980-12372

J117
White




90980-12372

Position of Parts in Instrument Panel (RHD)




J141
Black



90980-12372

J142
White



90980-12372