


Position of Parts in Engine Compartment (LHD)

* 5: Before Apr. 2018 Production
* 6: From Apr. 2018 Production



Position of Parts in Engine Compartment (LHD)

f1	Knock Control Sensor (Bank 1)
f2	Knock Control Sensor (Bank 2)
f8	Crank Position Sensor
i1	Front Wiper Motor & Link Assembly
j1	Front Shock Absorber Assembly RH , Skid Control Sensor Wire RH
j2	Front Shock Absorber Assembly LH , Skid Control Sensor Wire LH
m1	Inverter with Converter Assembly
m4	Inverter with Converter Assembly
m25	Inverter with Converter Assembly
m26	Inverter with Converter Assembly
n1	Compressor with Motor Assembly
n2	Inverter with Converter Assembly
p1	Front Television Camera Assembly
q1	No. 2 Front Motor Generator
q2	Inverter with Converter Assembly
r1	No. 1 Front Motor Generator
r2	Inverter with Converter Assembly
z1	No. 1 Cooling Fan Motor , No. 1 Cooling Fan ECU
z2	No. 2 Cooling Fan Motor , No. 2 Cooling Fan ECU
z29	Front Speed Sensor LH , Front Skid Control Sensor Wire LH
z30	Front Speed Sensor RH , Front Skid Control Sensor Wire RH

Position of Parts in Engine Compartment (LHD)

