



Position of Parts in Instrument Panel (LHD)




Position of Parts in Instrument Panel (LHD)

R1	Certification ECU
R9	Airbag Sensor Assembly
R32	Vehicle Approaching Speaker Controller
R38	No. 8 CAN Junction Connector
R39	No. 1 CAN Junction Terminal
S9	Airbag Sensor Assembly
S62	No. 11 CAN Junction Connector
V1	Rear Console Box Light (No. 1 Interior Illumination Light Assembly)
V2	Front Console Box Light (No. 1 Interior Illumination Light Assembly)
g1	Remote Operation Switch
m14	Power Steering Converter Assembly
m15	Power Steering Converter Assembly
m16	Power Steering Converter Assembly
m17	Power Steering Converter Assembly
m19	Power Steering Converter Assembly
z3	A/C Amplifier Assembly , A/C Unit (A/C Harness Assembly)
z4	Spiral Cable with Sensor Sub-Assembly , Steering Pad Switch Assembly
z5	Power Steering ECU Assembly , Electric Power Steering Column Sub-Assembly
z6	Driver Side Squib Circuit (Horn Button Assembly) , Spiral Cable with Sensor Sub-Assembly
z7	Driver Side Squib Circuit (Horn Button Assembly) , Spiral Cable with Sensor Sub-Assembly
z8	Cruise Control Main Switch , Spiral Cable with Sensor Sub-Assembly
z9	No. 1 Switch Wire , Spiral Cable with Sensor Sub-Assembly
z26	Steering Vibration and Heater ECU (Steering Wheel Assembly) , No. 1 Switch Wire , Spiral Cable with Sensor Sub-Assembly
z31	Driver Side Squib Circuit (Horn Button Assembly) , Spiral Cable with Sensor Sub-Assembly
z32	Driver Side Squib Circuit (Horn Button Assembly) , Spiral Cable with Sensor Sub-Assembly


Position of Parts in Instrument Panel (LHD)




90980-12B77




90980-12390




90980-12552




90980-12B54




82824-30470



90980-12392




90980-12B54




90980-11918




90980-11918




90980-12553




90980-12733




90980-12120




90980-11579




90980-10789




90980-12551




90980-12221




90980-12559




90980-12899



90980-12219



90980-12224



90980-12296

Position of Parts in Instrument Panel (LHD)

