INSTRUMENT PANEL SAFETY PAD

PRECAUTION

1. **PRECAUTION FOR VEHICLE WITH SRS AIRBAG AND SEAT BELT PRETENSIONER**
   (a) Some operations in this section may affect the SRS airbags. Prior to performing the corresponding operations, read the SRS airbag NOTICE (See page RS-1).
2. **WHEN DISCONNECTING BATTERY NEGATIVE TERMINAL**
   NOTICE:
   When disconnecting the cable from the negative battery terminal, initialize the following systems after the cable is reconnected.

System Name	See procedure
Lighting System (Adaptive Front-Lighting System)	LI-17
Power Window Control System	WS-12
Power Back Door System	ED-33
Sliding Roof System (for Standard)	RF-22
Sliding Roof System (for Multi-panel Moon Roof)	RF-4

COMPONENTS



w/ Navigation System:



MULTI-DISPLAY

w/o Navigation System:



CENTER CLUSTER
INTEGRATION SWITCH

RADIO RECEIVER





SHIFT LEVER KNOB SUB-ASSEMBLY

INSTRUMENT PANEL FINISH PANEL LOWER

CONSOLE PANEL UPPER FRONT

IP

P

B108535E10





TURN SIGNAL SWITCH ASSEMBLY
WITH SPIRAL CABLE SUB-ASSEMBLY

w/ Power Tilt and Power Telescopic:



TILT AND TELESCOPIC SWITCH



STEERING COLUMN COVER

STEERING WHEEL NO.2 COVER LOWER

STEERING WHEEL ASSEMBLY

STEERING WHEEL NO.3 COVER LOWER



50 (510, 37)

8.8 (90, 78 in.*lbf)

STEERING PAD

N*m (kgf*cm, ft.*lbf) : Specified torque

P

B112165E04

IP



COWL SIDE TRIM SUB-ASSEMBLY RH



COWL SIDE TRIM SUB-ASSEMBLY LH

FRONT DOOR SCUFF PLATE RH

FRONT DOOR SCUFF PLATE LH



COMBINATION METER ASSEMBLY



INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY



INSTRUMENT PANEL FINISH PANEL SUB-ASSEMBLY LOWER

IP

P

B108537E01



DRIVER SIDE KNEE AIRBAG ASSEMBLY



7.6 (77, 67 in.*lbf)



GLOVE COMPARTMENT DOOR ASSEMBLY



INSTRUMENT PANEL NO.2 UNDER COVER SUB-ASSEMBLY



FLOOR CARPET COVER CENTER LH



FLOOR CARPET COVER CENTER RH



INSTRUMENT PANEL FINISH PANEL LOWER CENTER

N*m (kgf*cm, ft.*lbf) : Specified torque

P

B108539E01

IP



IP

N*m (kgf*cm, ft.*lbf) : Specified torque

● Non-reusable part

P

B108538E01


<C>
INSTRUMENT PANEL NO.1 PIN
<C>
INSTRUMENT PANEL NO.1 PIN
INSTRUMENT PANEL NO.1 PIN
<C>
<C>
<C>
<C>
DEFROSTER NOZZLE ASSEMBLY
<C>
SIDE DEFROSTER NO.4 NOZZLE DUCT
<C>
SIDE DEFROSTER NO.3
NOZZLE DUCT
w/ Mark Levinson Speaker System:
SPEAKER HOLE
NO.1 COVER
INSTRUMENT PANEL NO.2
SPEAKER PANEL SUB-ASSEMBLY
INSTRUMENT PANEL NO.1 SPEAKER
PANEL SUB-ASSEMBLY
FRONT NO.2 SPEAKER
FRONT NO.2 SPEAKER
FRONT NO.2 SPEAKER
P
B108540E03

IP



DEFROSTER NOZZLE NO.1 GARNISH

<C>

SIDE DEFROSTER NO.2 NOZZLE DUCT

<C>

SIDE DEFROSTER NO.1 NOZZLE DUCT

<C> <C> <C> <C>



HEATER TO REGISTER NO.4 DUCT

<C> <C> <C> <C>



HEATER TO REGISTER NO.1 DUCT

<C> <C>



HEATER TO REGISTER CENTER SUB DUCT



SIDE DEFROSTER NO.2 NOZZLE

IP

SIDE DEFROSTER NO.1 NOZZLE

<C>



NETWORK GATEWAY ECU

P

B108541E03


w/o Navigation System:
NO.2 RADIO ANTENNA CORD
INSTRUMENT PANEL NO.2 WIRE
w/ Navigation System:
NO.2 RADIO ANTENNA CORD
AUTOMATIC LIGHT CONTROL SENSOR
INSTRUMENT PANEL SAFETY PAD
FRONT PASSENGER AIRBAG ASSEMBLY
GLOVE BOX LIGHT ASSEMBLY
<C>
INSTRUMENT PANEL BRACKET
SUB-ASSEMBLY CENTER
P
B108542E03

IP