

F RELAY LOCATIONS

Junction Connector (CAN RH)	Right Kick Panel (See Page 21)
--------------------------------	--------------------------------

