




- C 4 Center Cluster Integration Panel
- C 5 Center Speaker
- C 6 Cigarette Lighter
- C 7 Cigarette Lighter Illumination
- C 8 Combination Meter
- C 9 Combination Meter
- C 10 Combination SW
- C 11 Combination SW
- C 12 Combination SW
- C 13 Combination SW
- C 14 Console Box Illumination

- D 1 DLC3
- D 2 Double Door Lock ECU


- F 12 Front Power Outlet
- F 13 Front Squawker LH
- F 14 Front Squawker RH
- F 15 Fuel Lid Opener SW

- G 1 Gateway ECU
- G 2 Glove Box Light

- H 17 Headlight Beam Level Control ECU
- H 18 Headlight Cleaner SW
- H 20 Heated Oxygen Sensor (Bank 1 Sensor 2)
- H 29 Hybrid Vehicle Control ECU
- H 30 Hybrid Vehicle Control ECU
- H 31 Hybrid Vehicle Control ECU
- H 32 Hybrid Vehicle Control ECU
- H 33 Hybrid Vehicle Control ECU
- H 34 Hybrid Vehicle Control ECU

Position of Parts in Instrument Panel <RHD>

C 4
White



C 5
White




C 6
White




C 7
Gray




C 8
White




C 9
White




C 10
White




C 11
White



C 12
White




C 13
Black




C 14
White



D 1
White



D 2
Blue



F 12
White




F 13
White




F 14
White



F 15
White




G 1
White



G 2
Black



H 17
Gray



H 18
White




H 20
Gray




Position of Parts in Instrument Panel <RHD>


H 29
White




H 30
White




H 31
White



H 32
White



H 33
White



H 34
White

