

POWER BACK DOOR SYSTEM

DESCRIPTION

The power back door system enables the back door to be opened and closed automatically by a motor in accordance with the signals from the power back door opener/closer switch or the power back door switch of the transmitter.

In addition, a power back door closer switch has been provided at the back door for convenience.

- This system is optional equipment on all models.
- This system, which is controlled by the power back door ECU, operates when the conditions indicated below have been met.

Operating Conditions	• The power back door OFF switch is in ON condition*. • The shift lever is in P position. • The power back door opener/closer switch is pressed a minimum of 1 second, the power back door button on the transmitter is pressed a minimum of 1 second or the power back door closer switch is pressed.
----------------------	--

*: The state in which the switch is pressed.

System Diagram

