


■ REAR SEAT

Two ISO-FIX bars for securing child seats have been provided behind the seat cushion of the rear seat.
Three CRS anchor brackets for securing child seats have been provided behind the rear seat backrest.



■ SEAT BELT

1. General

- The following types of seat belts are provided.
- Seat belt comfort guides for child or small occupant have been added on the both sides of rear seats.

Seat	Seat Belt Type	Remarks
Driver & Front Passenger	3-point ELR* ¹	Electrical Sensing Type Pretensioner & Force Limiter
Rear Passenger	3-point ELR* ¹ & ALR* ²	-


*¹ : Emergency Locking Retractor

*² : Automatic Locking Retractor

2. Pretensioner and Force Limiter


- In accordance with the ignition signal from the airbag sensor assembly, the seat belt pretensioner activates simultaneously with the deployment of SRS airbag for the driver and front passenger.
In the beginning of the collision if the tension of the seat belt applied to the occupant reaches a predetermined level, the force limiter activates to control the force.

► Front Airbag Operation ◀



3. Seat Belt Comfort Guide

This belt comfort guides for child or small occupant have been added on the both sides of rear seats. With this device, the belt guide can be slid to a position to reduce seatbelt discomfort.



241BO19