1983 ONLY


IGNITION SWITCH
BLK/RED
BLK/WHT
SPARK PLUGS
BLU
BLU
SOLENOID VALVE
BLK/WHT
IGNITION COIL
E.S.S. RELAY
BLK
WHT
WHT/BLU
TO INSTRUMENT CLUSTER SYSTEM
IGNITION SWITCH
BLK/YEL
BLK/WHT
WHT
BLK/WHT OR WHT
FUSE 4 10A
FUSE 3 10A
FUSE LINK
M/T
A/T
BLK/YEL
INHIBITOR SWITCH
BLK/YEL
BLK/YEL
M/T
A/T
BLK/YEL
RED
RED/BLU
GRN
RED/BLU
BLU
FUSE LINK
CHARGE INDIC.
WHT
WHT
RED
ALTERNATOR
BLK
STARTING MOTOR
M
+
-
BATTERY